

ZIMMERMAN'S HIGH TUNNEL

Assembly/Installation Instructions



Zimmerman's Welding, LLC
11693 Sims Road • Versailles, MO 65084

Zimmerman's Welding, LLC

Neal Zimmerman

11693 Sims Road • Versailles, MO 65084

30' HIGH TUNNEL FRAME Assembly / Installation Instructions

When you receive your frame, check that you have everything as indicated on the list in the hardware box or boxes.

| <u>Step #</u> | <u>Activity</u> |
|----------------------|--|
| 1 | Level & Square Site |
| 2 | Drive Sidewall Poles |
| 3 | Assemble Bows |
| 4 | Set Bows |
| 5 | Side Walls: Bracing, Baseboards & Hip Boards |
| 6 | Roof Purlins & Roof Bracing |
| 7 | End Walls & C-Channel |
| 8 | Side Curtains |
| 9 | Roof Plastic |
| 10 | Door Installation |

NOTICE:

Before starting construction of high tunnel, consult the quote sheet for width, length, height and arch spacing of H-Tunnel